

HazMat Kits - Parts List

	ECD	ECDNS = ECD + NS Tools and Pins*	ECA = ECD + Ladder Patch	ECANS = ECD + Ladder Patch + NS Tools and Pins*	ECE = ECD + TBolt Patch	ECENS = ECD + TBolt Patch + NS Tools and Pins*	ECAE = ECD + TBolt Patch + Ladder Patch	ECAENS = ECD + TBolt Patch + Ladder Patch + NS Tools and Pins*	ECA1 = ECD** + TBolt Patch + Ladder Patch + Offset Devices	ECA1NS = ECD** + TBolt Patch + Ladder Patch + Offset Devices + NS Tools and Pins*	ECA
--	-----	---	-----------------------------------	--	-------------------------------	--	---	---	--	---	-----

Rev. 1 2023

Part#	Description	ECD	ECDNS	ECA	ECANS	ECE	ECENS	ECAE	ECAENS	ECA1	ECA1NS	ECA2
DP1	Ball Plug, 1-1/2"	1	1	1	1	1	1	1	1			
DP2	Ball Plug, 2"	1	1	1	1	1	1	1	1			
DP3	Taper Surface Plug, 1"	1	1	1	1	1	1	1	1			
DP4	Taper Surface Plug, 1-1/4"	1	1	1	1	1	1	1	1			
DP5	Taper Surface Plug, 1-1/2"	1	1	1	1	1	1	1	1			
DP6	Taper Surface Plug, 2"	1	1	1	1	1	1	1	1			
DP7	Taper Surface Plug, 2-1/2"	1	1	1	1	1	1	1	1			
DP8	Taper Surface Plug, 3"	1	1	1	1	1	1	1	1			
DT1	"T" Patch, 1-1/4" x 3-1/4"	1	1	1	1	1	1	1	1	1	1	
DT2	"T" Patch, 3-1/2" Sq.	1	1	1	1	1	1	1	1	1	1	
DS1	Screw Patch 6	1	1	1	1	1	1	1	1	1	1	
DS2	Screw Patch 8	1	1	1	1	1	1	1	1	1	1	
DS3	Screw Patch 10	1	1	1	1	1	1	1	1	1	1	
DS4	Screw Patch 12	1	1	1	1	1	1	1	1	1	1	
DS5	Screw Patch 14	1	1	1	1	1	1	1	1	1	1	
DW1	Lead Wool Pack	1	1	1	1	1	1	1	1	1	1	
DH1	Hot or Cold Hose Tape	1	1	1	1	1	1	1	1	1	1	
AF1	18" x 22" x 1/4" Foam			1	1	1	1	1	1	1	1	
DSP	18" x 18" Sorbent Pad	1	1	1	1	1	1	1	1	1	1	
DBT	Barrier Tape	1	1	1	1	1	1	1	1	1	1	
DPP	PND Plug Pattie	1	1	1	1	1	1	1	1	1	1	
DEP	Fix-Stix Epoxy Putty	1	1	1	1	1	1	1	1	1	1	
DNP	8"x12" Neoprene Material	1	1	1	1	1	1	1	1	1	1	
DWP	Wood Wedge Pack	1	1	1	1	1	1	1	1	1	1	
DSH	Rubber Safety Hammer	1	1	1	1	1	1	1	1	1	1	
DD1	Drift Pin Steel	1		1		1		1		1		
DTK	Tool Kit	1		1		1		1		1		
*DD1NS	Drift Pin NS: Non-Sparking		1		1		1		1		1	
*DTKNS	Tool Kit NS: Non-Sparking		1		1		1		1		1	
DBS	Steel Box	1	1	1	1	1	1	1	1	1	1	
Ladder Patch (Kits ECA, ECANS, ECAE & ECAENS)												
ARP	8" x 12" Hard Rubber Patch			1	1			1	1			
ASL	8" x 12" Support Ladder			1	1			1	1	1	1	
ASH	22ft. Nylon straps with ratch.			2	2			2	2	2	2	
T-Bolt Patch (Kits ECE, ECENS, ECAE, ECAENS, ECA1 & ECA1NS)												
A1TFP	8" x 12" Foam Patch for T-Bolts					1	1	1	1	1	1	
EWN	SS T-Bolts for 8x12 patch					3	3	3	3	3	3	
ECA1 Offset Devices												
A1OP8	Offset T-Bolt Surface Plug 8									1	1	
A1OP10	Offset T-Bolt Surface Plug 10									1	1	
A1OP11	Offset T-Bolt Surface Plug 11									1	1	
A1OP13	Offset T-Bolt Surface Plug 13									1	1	
A1TP8	T-Bolt Surface Plug 8									1	1	
A1TP10	T-Bolt Surface Plug 10									1	1	
A1TP11	T-Bolt Surface Plug 11									1	1	
A1TP13	T-Bolt Surface Plug 13									1	1	
A1TP1	"T" Patch 1									1	1	
A1TP3	"T" Patch 3									1	1	
A1LFP	8" x 12" Foam Patch for Ladder									1	1	
A1OTB	Offset SS T-Bolts for 8x12 w/ SS Wing-Nut Combos									3	3	
ECA2 Large Patch Plug Kit												
A2#16	Taper Surface Plug 5"											1
A2#9	T-Patch, 7" x 12"											1
A2#7	Ball Plug, 4"											1
A2C	Metal Box, 8" x 9" x 19"											1

*Non-Sparking Drift Pins and Tool Kit, **Kit-ECD without Ball & Taper Plugs